


Placement Instructions SOILTEX





LEGEND



quarry - wet, sand mixed with soiltex. 10 to 12 cm top layer of 3 times washed,



20 cm subsurface of 1 time washed sand



Solid underground

FORMULA: How many Kg SOILTEX do you need?

20 m * 40 m = 800 m²

 $3 \text{ kg} * 800 \text{ m}^2 = 2400 \text{ kg}$ SOILTEX

How to bring SOILTEX on?

about 6 cm deep with a milling machine. surface of the riding arena and then mill the Soiltex Scatter a coating of about 4cm Soiltex all over the







20 cm subsurface of 1 time washed sand





Solid underground



Drain pipes wrapped in pebbles